




RR standard 50cc 2008

21/12/07




**MOTORE AM6
K/S EU-2
RR**



Betamotor

N. CODE DESCRIZIPTION			N. CODE DESCRIZIPTION			N. CODE DESCRIZIPTION			N. CODE DESCRIZIPTION		
1	27-13551	BREATHER PIPE HOSE	3540	34-00380	PLATE CLUTCH	5398	34-00970	OIL SEAL	34-01510	WASHER PLAIN	
2	12-08280	COIL SCREENED CABLE	3551	34-02300	PLATE FRICTION 2	5603	34-00980	IMPELLER SHAFT ASSY	49151	34-01520	WASHER PLAIN
3	11-20632-8	H.T. COIL RR-AM6	4001	34-00400	DRIVEN GEAR ASSY	5605	34-00990	ROD, PUSH	49155	34-01530	WASHER PLAIN
4	21-55041	KICK STARTER LEVER ASSY	4017	34-00410	BOSS CLUTCH	5611	34-01000	PIN RETAINER	49175	34-01540	WASHER PLAIN
5	21-21225	SHIFT LEVER	4022	34-00420	GEAR 2ND PINION (16T)	5612	34-01010	THERMOSTAT ASSY	49191	34-01550	WASHER
6	12-67926-0-57	SPROCKET COVER	4023	34-00430	GEAR 3RD-4TH PINION (19-22T)	5615	34-01020	DOWEL	49192	34-01560	WASHER LOCK
15	34-02101	CARBURETOR	4025	34-00440	GEAR 5TH PINION (24T)	5616	34-01030	PIN DOWEL	49193	34-01570	WASHER PLATE
19	34-02113	BODY CYLINDER	4026	34-00450	GEAR 6TH PINION (25T)	5636	34-01040	PIN	49200	34-01580	SCREW FOR CLUTCH
62	34-00030	PISTON	4031	34-00460	GEAR 1ST WHEEL (36T)	5637	34-01050	PIN	49226	34-01600	SCREW
77	34-02230	HEAD CYLINDER 1	4032	34-00470	GEAR 2ND WHEEL (33T)	5645	34-01060	NEUTRAL SWITCH ASSY	49227	34-01610	SCREW
			4033	34-00480	GEAR 3RD WHEEL (29T)	5650	34-01070	PIN	49228	34-01620	BOLT
99	34-00060	SHIFT CAM	4034	34-00490	GEAR 4TH WHEEL (27T)	5653	34-01080	AXLE DRIVE GEAR	49230	34-01630	SCREW WITH WASHER
111	34-02240	PLUG SPARK	4035	34-00500	GEAR 5TH WHEEL (25T)	5661	34-01090	PIN DOWEL	49236	34-01640	BOLT HEXAGON SOCKET
212	34-00081	COVER CLUTCH SIDE	4036	34-00510	GEAR 6TH WHEEL (24T)	5663	34-01100	PIN DOWEL	49238	34-01650	BOLT HEXAGON SOCKET
213	34-00091	COVER OIL PUMP	4040	34-00520	IDLE GEAR	5665	34-01110	ROD, PUSH	49244	34-02190	BOLT HEXAGON SOCKET
214	34-00101	COVER FLYWHEEL SIDE	4045	34-00530	STARTING GEAR	5670	34-01120	PIN PISTON	49245	34-01670	BOLT HEXAGON SOCKET
332	34-00110	FORK	4048	34-00540	GEAR IMPELLER SHAFT	6013	34-01130	COVER HOUSING	49246	34-01680	BOLT HEXAGON SOCKET
333	34-00120	FORK 1	4049	34-00550	PUMP DRIVEN GEAR	6015	34-02340	REED VALVE ASSY	49248	34-01690	BOLT HEXAGON SOCKET
334	34-00130	FORK 2	4060	34-00560	GEAR DRIVE	9323	34-01150	STOP RING	49251	34-01700	BOLT HEXAGON SOCKET
335	34-00140	FORK 3	4061	34-00570	GEAR BALANCE WEIGHT	9351	34-01160	CIRCLIP	49255	34-01710	BOLT HEXAGON SOCKET
381	34-02250	CRANKSHAFT ASSY	4066	34-00580	STARTING SLIDING	9352	34-01170	CIRCLIP	49281	34-01720	BOLT HEXAGON HEAD
382	34-02260	CONNECTING ROD COMPLETE				9355	34-01180	CIRCLIP	49290	34-01730	BOLT HEXAGON
435	34-00170	PUSH LEVER ASSY	4620	34-00600	SPRING COMPRESSION	9356	34-01190	CIRCLIP	49292	34-02180	SCREW
471	34-00180	SPRING TORSION HUB	4625	34-00610	SPRING	9362	34-01200	SNAP RING	49294	34-01740	SCREW
582	34-02210	SPROCKET TH.11	4635	34-00620	SPRING	9363	34-01210	SNAP RING	34-02430	THERMOSTAT ASSY	
606	27-19791	MANIFOLD	4650	34-00630	SPRING	9365	34-01220	CIRCLIP	49405	34-02350	GASKET
641	34-02271	OIL PUMP -MIKUNI-	4655	34-00640	SPRING	15270	34-01230	OIL BREATHER PIPE	49528	34-01241	KIT DEVIATING PIPE
657	34-00210	HOLDER	4660	34-00650	SPRING TORSION	24107	34-02140	PIPE 2	49840	34-01750	SCREW
658	34-00220	HOLDER	4665	34-00660	SPRING	49004	34-01250	CLIP	53309	34-00821	GASKET H.COVER 2
681	34-02280	PISTON RING SET (STD)	4680	34-00670	WASHER CONICAL SPRING	49005	34-02160	CLAMP HOSE	53310	34-01761	GASKET H.COVER 1
701	34-02220	CRANKCASE ASSY	5101	34-00680	NEEDLE BEARING	49007	34-01260	CLAMP	53508	34-01770	OIL SEAL
820	28-97810	BASE ASSY	5106	34-00690	BUSH SOLID	49009	34-01270	KEY			
826	27-00361	ROTOR ASSY	5113	34-00700	ROLLER BEARING	49010	34-01280	KEY			
828	25-60166	PLATE	5146	34-00710	BEARING	49015	34-01290	KEY			
911	34-00240	AXLE MAIN	5148	34-00720	BEARING	49022	34-02170	CLAMP HOSE			
912	34-00250	KICK STARTER SHAFT	5156	34-00730	BEARING	49035	34-01300	NUT HEXAGON			
914	34-00260	AXLE DRIVE	5172	34-00740	BEARING	49037	34-01310	NUT CAP			
915	34-00270	SHIFT SHAFT	5178	34-00750	BEARING	49040	34-01320	NUT HEXAGON	13-32366-3	FLYWELL COVER DECALCS	
917	34-00280	WEIGHT 1	5181	34-00760	BALL	49041	34-01330	NUT HEXAGON	13-32366-4	CLUTCH COVER DECALCS	
2430	34-00291	RUBBER	5182	34-00770	BALL	49042	34-01340	NUT HEXAGON			
2467	34-00300	JT.HOSE 2	5303	34-00790	O-RING	49049	34-01350	NUT HEXAGON	34-01780	AXLE MAIN ASSY	
			5308	34-00800	O-RING	49056	34-01360	NUT	34-01790	AXLE DRIVE ASSY	
2478	34-00321	RUBBER	5310	34-02200	O-RING	49068	34-01370	FORK SPACER	34-02121	COVER ASSY (GOLD STAMP)	
2492	34-00330	PLUG, OIL	5315	34-00831	O-RING	49070	34-01380	COLLAR	34-01810	GEAR BOX ASSY	
			5318	34-00840	O-RING	49074	34-01390	PLATE THRUST	34-01820	CLUTCH GEARS	
2607	34-01241	KIT DEVIATING PIPE	5320	34-00850	GASKET CYLINDER	49084	34-01400	BOLT STUD	34-01831	GASKET SET	
2635	34-02150	CLAMP	5327	34-00860	GASKET CRANKCASE COVER 2	49095	34-01410	WASHER PLAIN	34-01840	OIL SEAL SET	
			5341	34-00870	GASKET HOUSING COVER	49099	34-01241	KIT DEVIATING PIPE	34-02370	PISTON ASSY (STD)	
3511	34-00370	PLATE PRESSURE	5357	34-00880	GASKET	49101	34-01420	WASHER TOOTHED LOCK	34-02380	PISTON ASSY (OVERSIZE)	
			5358	34-00890	GASKET	49120	34-01430	WASHER PLAIN	34-02390	PISTON RING SET OVERSIZE	
			5359	34-00900	WASHER PLAIN	49122	34-01440	WASHER PLAIN	34-02400	CYLINDER-PISTON ASSY	
			5361	34-00910	GASKET	49124	34-01450	WASHER PLAIN	31-03266	FLY-WHEEL ASSY	
			5362	34-00920	GASKET	49131	34-01460	WASHER			
			5371	34-02310	OIL SEAL	49132	34-01470	PLATE THRUST			
			5372	34-02320	OIL SEAL	49135	34-01480	WASHER PLAIN			
			5376	34-02330	OIL SEAL		34-01490	WASHER PLAIN			
			5395	34-00960	OIL SEAL	49139	34-01500	WASHER PLAIN			

SUPPLEMENTARY PARTS LIST



N.	CODICE	DESCRIZIONE	N.	CODICE	DESCRIZIONE	N.	CODICE	DESCRIZIONE	N.	CODICE	DESCRIZIONE
1	22.20550.0.59	HANDLEBAR	63	12.96005	BEARING	130	12.81430	TIRE 3.50x18	196	29.15811	GASOLINE TUBE
2	12.08982	THROTTLE KIT	64	13.85073	LH FRONT HUB SPACER	131	12.18310	TUBE 3.50x18	197	31.02170	TANK VALVE
3	29.21983.0.52	THROTTLE CABLE	65	22.03411.0.59	MUFFLER	132	15.36000	BEAD 17-18x25	198	31.89010	SEAT BLOCKING SCREW
4	12.09386	SPEEDOMETER	66	22.48980	SPRING	133	13.39415	REAR BRAKE DISK	199	31.30530	SCREW
5	12.73620	SPEEDOMETER COVER	67	12.54905	MUFFLER COLLECTOR	134	13.85728	WHEEL HUB RH SPACER	200	31.89100	FILTER BOX SPECIAL SCREW
6	28.95442	SPEEDOMETER BRACKET	68	29.09523	FRONT BRAKE HOSE	135	25.55621	REAR WHEEL AXLE	201	27.28093	REGULATOR
7	16.34905	GROMMET	69	16.50510	COPPER WASHER 10x15x1	136	25.24410	SPLASH-GUARD	202	27.23562	RECTIFIER
8	13.13020	SELF-BLOCKING NUT	70	29.15793	LOWER RADIATOR PIPE	137	15.15555	CLAMP	203	12.73194.0.52	FILTER COVER
9	13.46686	SPACER	71	29.15698	UPPER RADIATOR PIPE	138	22.13583	RUBBER SLEEVE	204	28.12775.0.52	AIR FILTER BOX
10	18.01576	SPEEDOMETER ELECT. EQUIPMENT	72	15.15240	CLAMP	139	15.15360	CLAMP	205	15.25081	AIR FILTER
11	28.03582	LOCKS KIT	73	29.15811	TUBE	140	15.23101.1.XX	LH RADIATOR COVER	206	14.40040	ELASTIC RUBBER
12	12.55287	IGNITION SWITCH	74	28.92100	SILENT BLOCK	141	10.04009	SHOCK ABSORBER	207	28.01649	SEAT
13	31.23125	SCREW	75	16.45533.0.59	LH RADIATOR COVER		10.04015	SHORT SHOCK ABSORBER	208	20.02044	SEAT LOCKING KIT
14	28.92889	OIL INDICATOR LIGHTS	76	10.52000	OIL SEAL	142	13.19010	SELF-BLOCKING NUT	209	15.19841.1.XX	RH BODY SIDE NUMBER HOLDER
	28.92895	DIRECTION INDICATORS LIGHTS	77	27.81210	PETCOCK	143	27.54000	WASHER	210	25.19666.1.YY	REAR FENDER
	28.92896	LOW BEAM LIGHTS	78	15.15220	CLAMP	144	11.62000	BOLT	211	25.94477.1.59	NUMBER PLATE HOLDER ONLY
	28.92897	HIGH BEAM LIGHTS	79	28.85380.0.66	OIL TANK	145	25.03073.0.59	REAR BRAKE PLIERS	212	15.01767	REAR LIGHT
	28.92898	NEUTRAL BEAM LIGHTS	80	13.82551	SPACER	146	16.50510	COPPER GASKET	213	18.01578	MAIN ELECT. EQUIPMENT
	28.23100	SEEGER 14E	81	22.65020	TUBE SPRING	147	29.09512	REAR BRAKE HOSE	214	29.11364.0.25	REAR FRAME
15	21.16720	WARNING LIGHTS LAMP	82	25.91181	REAR BRAKE PUMP	148	11.65040	SPEC. BOLT BRAKE TUBE	215	25.57691	PLATE
16	13.36695	SWITCH	83	10.84040	REAR BRAKE ROD	149	11.64605	SPECIAL BOLT	216	12.33085	REAR REFLECTOR
17	18.01581	MAIN ELECTRIC EQUIPMENT	84	28.93130	BRAKE ROD LOCKING PLATE	150	10.41190	DUST RING	217	28.91786	SILENCER
18	22.18511	GRIP	85	22.48810	RET BRAKE PEDAL SPRING	151	10.41190	DUST RING	218	31.64070	SCREW
19	21.27086	CLUTCH LEVER ONLY	86	22.90060	FOOTREST HUB	152	10.84540.8	ROD SELECTOR SHAFT	219	27.49500	WASHER 8x18
20	21.02394	CLUTCH LEVER	87	28.91947	SILENT BLOCK	153	21.21230	SHIFT LEVER	220	13.46905	SPACER
21	29.12781	STARTER TRANSMISSION	88	31-30475	SCREW	154	25.98680	SPHERIC ARTICOL PROTECTION	221	28.92101	SILENT-BLOCK
22	29.14763	CLUTCH TRANSMISSION	89	31-30475	SCREW	155	21.70173.8	PIN LEVER SELECTOR SHAFT	222	13.17020	SELF BLOCKING NUT M8
23	11.65040	SPEC. BOLT BRAKE TUBE	90	25.98909	SILENCER SHIELD	156	25.33051	LH FOOTREST	223	16.33780	GROMMET
24	16.50510	COPPER WASHER 10x15x1	91	28.91943	SILENT-BLOCK	157	22.62020	LH FOOTREST SPRING		16.33781	THERMAL GROMMET
25	29.09523	FRONT BRAKE HOSE	92	11.49070	BOLT 6x20	158	13.46530	SPACER	224	25.24657.1.YY	REAR WHEELHOUSE
26	16.50510	COPPER WASHER 10x15x1	93	27.42000	WASHER 6x18	159	11.55700	BOLT	225	13.54510	SPLASH-GUARD SPACER
27	21.27105	FRONT BRAKE LEVER ONLY	94	16.47490	GASKET	160	27.64500	WASHER	226	16.34510	RUBBER
28	21.02062	FRONT BRAKE LEVER	95	11.48025	BOLT 6x16	161	11.64600	BOLT	227	22.12120	RUBBER SLEEVE
29	22.28471.1.XX	HEADLIGHT HOLDER	96	25.26220	FOOT BRAKE LEVEL	162	16.50510	COPPER WASHER 10x15x1	228	13.54510	SPACER
30	14.40083	FRONT LIGHT STRAP	97	11.31030	SINTERED BUSHING	163	29.09512	REAR BRAKE HOSE	229	11.48025	BOLT 6x16
31	13.49190	SPACER	98	10.41190	DUST RING	164	16.50510	COPPER WASHER 10x15x1	230	27.24811	SPOKE Ø 3.5x203
32	28.98278.1.33	FRONT FENDER BRACKET	99	13.21120	SELF-BLOCKING NUT	165	18.89622	STOP SWITCH	231	27.24812	SPOKE Ø 3.5x206
33	12.93085	FRONT HEADLIGHT COWLING	100	27.55600	WASHER	166	22.62010	RH FOOTREST SPRING	232	23.10110	SPECIAL NIPPLES
34	16.46205	HEADLIGHT	101	11.22024	BUSH	167	25.33001	RH FOOTREST	233	15.19851.1.XX	LF BODY SIDE NUMBER HOLDER
35	18.01556	FRONT ELECTRIC EQUIPMENT	102	11.22024	BUSH	168	10.09180	HORN	234	11.49070	BOLT 6x20
36	25.14338.1.XX	FRONT FENDER	103	13.48068	SPACER	169	29.00550	OIL TANK CAP	235	13.62000	SPACER
37	25.57255.1.36	FRONT BRAKE TUBE PLATE	104	29.10090.0.52	SLIDING BLOCK	170	29.15811	TUBE	236	13.48861	TANK SPACER
38	15.14610.0.52	FRONT BRAKE TUBE CLAMP	105	15.62098	SWINGING ARM	171	27.23744	RADIATOR			SUPPLEMENTARY PARTS LIST
39	29.09523	FRONT BRAKE HOSE	106	25.55730	S/ARM SPINDLE	172	28.85861	LOCKS KIT	12.33060		REFLECTOR
40	13.49197	SPACER	107	25.57634	STAND SPRING PLATE	173	12.55915	COVER LOCK	12.43030		SPARK KEY
41	16.50510	COPPER WASHER 10x15x1	108	12.39956.0.66	STAND	174	29.01260	RADIATOR CAP	13.32366.5		DECALS, ENGINE COVER
42	25.03084	FRONT BRAKE PLIERS	109	11.70021	SPECIAL BOLT	175	16.45532.0.59	RH RADIATOR COVER	13.32383.0.XX		DECALCS SET
43	25.03091	FRONT BRAKE PLIERS	110	27.79430	CHAIN ROLLER	176	25.98751	STEERING BEARINGS PROTECT	13.46687		NUMBER PLATE SPACER
44	15.08122	FRONT FORK	111	13.46580	SPACER	177	12.99300	CONICAL BEARING	15.02512		LEFT PANEL THERMAL PAD
45	27.23981	FRONT SPOKE 3x240	112	22.11183	CONNECTING LINK	178	29.11324.0.25	FRAME	15.02513		MUFFLER THERMAL PAD PROTECTION
46	27.23982	FRONT SPOKE 3x242	113	12.08201	CHAIN	179	27.23470	BREATHER PIPE HOSE	15.02514		AIR FILTER THERMAL PAD
47	23.10100	NIPPLES	114	29.10120.0.52	SLIDING BLOCK	180	27.73790	WASHER	18.12611		RH FRONT INDICAT.
48	29.25271.0.52	SPEEDOMETER TRANSMISSION	115	22.47028	OUTSER STAND SPRING	181	25.98781	STEERING BEARINGS PROTECT.	18.12614		LH FRONT INDICAT.
49	27.32473	SPEEDOMETER DRIVING GEAR	116	22.47027	OUTSER STAND SPRING	182	15.23111.1.XX	RH RADIATOR COVER	18.12621		RH REAR INDICAT.
50	25.55742	FRONT WHEEL AXLE	117	15.14300	CLAMP	183	28.05100	BRAKE OIL TANK	18.12624		LH REAR INDICAT.
51	13.85439	WHEEL HUB RH SPACER	118	29.06201	CHAIN TENSIONER	184	27.11260	CONNECTOR WITH OIL FILTER	27.02579.0.57		FRONT WHEEL
52	12.96005	BEARING	119	12.88591.1.59	CHAINGUARD	185	15.24651	GASOLINE FILTER	27.04806.0.57		REAR WHEEL
53	15.38200	BEAD 21	120	15.17550	TIRE FASTENER	186	29.15811	GASOLINE TUBE	28.92925		MIRROR
54	12.16110	TUBE 2.50x21/2.75x21	121	13.17120	NUT	187	27.79830	PETCOCK			
55	12.79132	TIRE 80/90-21 48P	122	13.29600	NUT	188	25.95220	TANK FIXING PLATE			
56	12.42932	RIM 21	123	27.71210	WASHER 17x31x3	189	29.15867	TUBE			
57	22.07251	FRONT HUB	124	13.85737	WHEEL HUB LH SPACER	190	29.15854	TUBE			
58	13.62728	WHEEL HUB INNER SPACER	125	12.97005	BEARING	191	31.15040	VALVE			
59	31.63922	SCREW TSPCE 8x16	126	12.89626	REAR SPROCKET	192	27.11320	BREATHER PIPE HOSE			
60	13.39282	FRONT BRAKE DISK	127	13.62727	WHEEL HUB INNER SPACER	193	16.33785	GROMMET			
61	15.17500	TIRE FASTENER	128	12.42942	RIM 18	194	28.06031.0.59	TANK			
62	13.17120	NUT	129	22.08050	REAR HUB	195	29.10511	TANK PLUG			

PAINT XX=48 e YY=19 for ORANGE/GREY

PAINT XX=37 e YY=37 for BLUE

PAINT XX=97 e YY=97 for RED



RR 50cc 2008

21/12/07