





N.	CODICE	DESCRIZIONE	N.	CODICE	DESCRIZIONE	N.	CODICE	DESCRIZIONE	N.	CODICE	DESCRIZIONE
1	22.20480.0.57	HANDLEBAR	70	29.15811	TUBE	139	13.29600	NUT	207	31.15040	VALVE
2	12.08982	THROTTLE KIT	71	28.92100	SILENT BLOCK	140	27.71210	WASHER 17x31x3	208	27.11320	BREATHER PIPE HOSE
3	29.21979.0.52	THROTTLE CABLE	72	16.45533.0.59	LH RADIATOR COVER	141	13.85737	WHEEL HUB LH SPACER	209	16.33785	GROMMET
4	12.09387	SPEEDOMETER	73	10.52000	OIL SEAL	142	12.98010	BEARING	210	28.06031.0.59	TANK
5	16.34902	GROMMET	74	27.81210	PETCOCK	143	12.89626	REAR SPROCKET	211	29.10511	TANK PLUG
6	13.46688	SPACER	75	15.15220	CLAMP	144	13.62727	WHEEL HUB INNER SPACER	212	29.15811	GASOLINE TUBE
7	12.55291	LOCKS KIT	76	28.85380.0.66	OIL TANK	145	12.42943	RIM 18	213	31.02170	TANK VALVE
8	16-20640	BLOCK-RING	77	13.82551	SPACER	146	12.81430	TIRE 3.50x18	214	31.89010	SEAT BLOCKING SCREW
9	13.36695	SWITCH	78	22.65020	TUBE SPRING	147	12.18310	TUBE 3.50x18	215	31.30530	SCREW
10	18.01579	MAIN ELECTRIC EQUIPMENT	79	25.91181	REAR BRAKE PUMP	148	15.36000	BEAD 17-18x25	216	31.89100	FILTER BOX SPECIAL SCREW
11	22.18511	GRIP	80	10.84040	REAR BRAKE ROD	149	22.08046	REAR HUB	217	27.23562	RECTIFIER
12	21.27086	CLUTCH LEVER ONLY	81	28.93130	BRAKE ROD LOCKING PLATE	150	13.39415	REAR BRAKE DISK	218	27.28093	REGULATOR
13	21.02394	CLUTCH LEVER	82	22.48810	RET BRAKE PEDAL SPRING	151	12.98010	BEARING	219	12.73194.0.52	FILTER COVER
14	29.12781	STARTER TRANSMISSION	83	22.90060	FOOTREST HUB	152	13.85728	WHEEL HUB RH SPACER	220	28.12775.0.52	AIR FILTER BOX
15	29.14763	CLUTCH TRANSMISSION	84	28.91947	SILENT BLOCK	153	25.55621	REAR WHEEL AXLE	221	15.25081	AIR FILTER
16	11.65040	SPEC. BOLT BRAKE TUBE	85	31-30475	SCREW	154	25.24410	SPLASH-GUARD	222	14.40040	ELASTIC RUBBER
17	16.50510	COPPER WASHER 10x15x1	86	13.19010	SELF-BLOCKING NUT	155	15.15555	CLAMP	223	28.01648	SEAT
18	29.09524	FRONT BRAKE HOSE	87	13.19010	SELF-BLOCKING NUT	156	22.13583	RUBBER SLEEVE	224	20.02030	SEAT LOCKING KIT
19	16.50510	COPPER WASHER 10x15x1	88	11.20470	CONNECTING ARM	157	15.15360	CLAMP	225	15.19841.1.XX	RH BODY SIDE NUMBER HOLDER
20	21.02062	FRONT BRAKE LEVER	89	31-30475	SCREW	158	15.23101.1.XX	LH RADIATOR COVER	226	25.19665.1.XX	REAR FENDER
21	21.27105	FRONT BRAKE LEVER ONLY	90	25.98909	SILENCER SHIELD	159	10.04008	SHOCK ABSORBER	227	25.94477.1.59	NUMBER PLATE HOLDER ONLY
22	22.28471.1.XX	HEADLIGHT HOLDER	91	28.91943	SILENT-BLOCK	160	13.19010	SHORT SHOCK ABSORBER	228	15.01767	REAR LIGHT
23	14.40082	FRONT LIGHT STRAP	92	11.49070	BOLT 6x20	161	27.54000	SELF-BLOCKING NUT	229	18.01578	MAIN ELECT. EQUIPMENT
24	13.49190	SPACER	93	27.42000	WASHER 6x18	162	11.62000	WASHER	230	29.11364.0.25	REAR FRAME
25	13.49190	SPACER	94	16.47490	GASKET	163	25.03073	BOLT	231	25.57691	PLATE
26	28.98278.1.33	FRONT FENDER BRACKET	95	11.49070	BOLT	164	16.50510	REAR BRAKE PLIERS	232	12.33085	REAR REFLECTOR
27	12.93085	FRONT HEADLIGHT COWLING	96	13.17020	SELF-BLOCKING NUT	165	29.09512	COPPER GASKET	233	28.91783	SILENCER
28	16.46205	HEADLIGHT	97	11.19830.0.57	CONNECTING ROD	166	11.65040	REAR BRAKE HOSE	234	31.64070	SCREW
29	18.01556	FRONT ELECTRIC EQUIPMENT	98	11.23200	NEEDLE BEARING	167	11.64605	SPEC. BOLT BRAKE TUBE	235	27.49500	WASHER 8x18
30	25.14336.1.YY	FRONT FENDER	99	13.46851	SPACER	168	10.41190	SPECIAL BOLT	236	13.46905	SPACER
31	25.57255.1.36	FRONT BRAKE TUBE PLATE	100	11.55500	SCREW	169	10.41190	DUST RING	237	28.92101	SILENT-BLOCK
32	15.14649	FRONT BRAKE TUBE CLAMP	101	11.22450	NEEDLE BEARING	170	10.84540.8	SELF-BLOCKING NUT M8	238	13.17020	GROMMET
33	25.24442	FAIR LEAD 6/8	102	13.47710	SPACER	171	21.21230	SHIFT LEVER	239	16.33780	REFLECTOR
34	29.09524	FRONT BRAKE HOSE	103	10.66620	OIL SEAL	172	25.98680	SPHERIC ARTICOL PROTECTION	240	25.24657.1.XX	REAR WHEELHOUSE
35	25.24443	FAIR LEAD 8/8	104	28.14090	RETAINER	173	21.70173.8	PIN LEVER SELECTOR SHAFT	241	13.54510	SPLASH-GUARD SPACER
36	16.50510	COPPER WASHER 10x15x1	105	27.54000	WASHER	174	25.33050	LH FOOTREST	242	16.34510	RUBBER
37	16.50510	COPPER WASHER 10x15x1	106	11.63880	BOLT	175	22.62020	LH FOOTREST SPRING	243	15.14296	CLAMP
38	11.65040	SPEC. BOLT BRAKE TUBE	107	11.63710	BOLT	176	13.46530	SPACER	244	13.54510	SPACER
39	22.11000	SENSOR REED MAGNETO	108	27.54000	WASHER	177	11.55700	BOLT	245	11.48025	BOLT 6x16
40	27.58080	WASHER	109	27.54250	WASHER	178	27.64500	WASHER	246	27.24811	SPOKE Ø 3.5x203
41	28.22660	SEEGER 9E	110	10.41195	DUST RING	179	11.64600	BOLT	247	27.24812	SPOKE Ø 3.5x206
42	25.03087	FRONT BRAKE PLIERS	111	13.47610	SPACER	180	16.50510	COPPER WASHER 10x15x1	248	23.10110	SPECIAL NIPPLES
43	15.08118	FRONT FORK	112	11.22850	NEEDLE BEARING	181	29.09512	REAR BRAKE HOSE	249	15.19851.1.XX	LF BODY SIDE NUMBER HOLDER
44	27.23981	FRONT SPOKE 3x240	113	25.26220	FOOT BRAKE LEVEL	182	18.89622	STOP SWITCH	250	11.49070	BOLT 6x20
45	23.10100	NIPPLES	114	11.31030	SINTERED BUSHING	183	22.62010	RH FOOTREST SPRING	251	13.62000	SPACER
46	27.23982	FRONT SPOKE 3x242	115	10.41190	DUST RING	184	25.33000	RH FOOTREST			
47	25.55741	FRONT WHEEL AXLE	116	13.21120	SELF-BLOCKING NUT	185	10.09180	HORN			
48	13.85434	WHEEL HUB RH SPACER	117	27.55600	WASHER	186	29.00550	OIL TANK CAP			
49	12.98010	BEARING	118	11.22024	BUSH	187	27.23744	RADIATOR			
50	15.38200	BEAD 21	119	11.22024	BUSH	188	28.85861	LOCKS KIT			
51	12.16110	TUBE 2.50x21/2.75x21	120	13.48068	SPACER	189	12.55915	COVER LOCK			
52	12.79132	TIRE 80/90-2148P	121	29.10090.0.52	SLIDING BLOCK	190	29.01260	RADIATOR CAP			
53	12.42934	RIM 21	122	15.62097	SWINGING ARM	191	16.45532.0.59	RH RADIATOR COVER			
54	22.07251	FRONT HUB	123	25.55730	S/ARM SPINDLE	192	25.98751	STEERING BEARINGS PROTECT			
55	13.62728	WHEEL HUB INNER SPACER	124	25.57634	STAND SPRING PLATE	193	12.99300	CONICAL BEARING 20x42x15			
56	31.63922	SCREW TSPCE 8x16	125	12.39956.0.66	STAND	194	29.11323.0.25	FRAME			
57	13.39282	FRONT BRAKE DISK	126	11.70021	SPECIAL BOLT	195	27.23470	BREATHER PIPE HOSE			
58	15.17500	TIRE FASTENER	127	27.79430	CHAIN ROLLER	196	27.73790	WASHER			
59	13.17120	NUT	128	13.46580	SPACER	197	25.98781	STEERING BEARINGS PROTECT.			
60	12.98010	BEARING	129	22.11183	CONNECTING LINK	198	15.23111.1.XX	RH RADIATOR COVER			
61	13.85073	LH FRONT HUB SPACER	130	12.08201	CHAIN	199	28.05100	BRAKE OIL TANK			
62	22.03404.0.59	MUFFLER	131	29.10120.0.52	SLIDING BLOCK	200	27.11260	CONNECTOR WITH OIL FILTER			
63	22.48980	SPRING	132	22.47028	OUTER STAND SPRING	201	15.24651	GASOLINE FILTER			
64	12.54905	MUFFLER COLLECTOR	133	22.47027	OUTER STAND SPRING	202	29.15811	GASOLINE TUBE			
65	28.79011	REED SENSOR	134	15.14300	CLAMP	203	27.79830	PETCOCK			
66	29.15793	LOWER RADIATOR PIPE	135	29.06200	CHAIN TENSIONER	204	25.95220	TANK FIXING PLATE			
67	29.15698	UPPER RADIATOR PIPE	136	12.88591.1.59	CHAIN GUARD	205	29.15867	TUBE			
68	15.15240	CLAMP	137	15.17550	TIRE FASTENER	206	29.15854	TUBE			
69	15.15240	CLAMP	138	13.17000	NUT						

SUPPLEMENTARY PARTS LIST

12.33060	REFLECTOR	53 FOR RED
12.43030	SPARK KEY	
13.32366.5	DECALS, ENGINE COVER	
13.32371.0.XX	DECALS SET	
13.46687	NUMBER PLATE SPACER	
15.02512	LEFT PANEL THERMAL PAD	
15.02513	MUFFLER THERMAL PAD PROTECTION	
15.02514	AIR FILTER THERMAL PAD	
18.12611	RH FRONT INDICAT.	
18.12614	LH FRONT INDICAT.	
18.12621	RH REAR INDICAT.	
18.12624	LH REAR INDICAT.	
27.02577.0.57	FRONT WHEEL	
27.04799.0.57	REAR WHEEL	
28.92925	MIRROR	

PAINT XX = 48 FOR ORANGE GREY 53 FOR RED
93 FOR YELLOW BLUE 97 FOR FLOU-RED

PAINT YY = 19 FOR ORANGE GREY 53 FOR RED
37 FOR YELLOW BLUE 97 FOR FLOU-RED





ENGINE RR 50cc AM6 (FE) EURO-2 CODE 37-60550-200

FROM ENGINE NR. 51ED000001

ES-ME321

N.	CODE	DESCRIZIPTION	N.	CODE	DESCRIZIPTION	N.	CODE	DESCRIZIPTION	N.	CODE	DESCRIZIPTION
1	27-13551	BREATHER PIPE HOSE	3540	34-00380	PLATE CLUTCH	5398	34-00970	OIL SEAL	34-01510	WASHER PLAIN	
2	12-08280	COIL SCREENED CABLE	3551	34-02300	PLATE FRICTION 2	5603	34-00980	IMPELLER SHAFT ASSY	49151	34-01520	WASHER PLAIN
3	11-20632-8	H.T. COIL RR-AM6	4001	34-00400	DRIVEN GEAR ASSY	5605	34-00990	ROD, PUSH	49155	34-01530	WASHER PLAIN
4	21-55041	KICK STARTER LEVER ASSY	4017	34-00410	BOSS CLUTCH	5611	34-01000	PIN RETAINER	49175	34-01540	WASHER PLAIN
5	21-21225	SHIFT LEVER	4022	34-00420	GEAR 2ND PINION (16T)	5612	34-01010	THERMOSTAT ASSY	49191	34-01550	WASHER
6	12-67926-0-57	SPROCKET COVER	4023	34-00430	GEAR 3RD-4TH PINION (19-22T)	5615	34-01020	DOWEL	49192	34-01560	WASHER LOCK
15	34-02101	CARBURETOR	4025	34-00440	GEAR 5TH PINION (24T)	5616	34-01030	PIN DOWEL	49193	34-01570	WASHER PLATE
19	34-02113	BODY CYLINDER	4026	34-00450	GEAR 6TH PINION (25T)	5636	34-01040	PIN	49200	34-01580	SCREW FOR CLUTCH
62	34-00030	PISTON	4031	34-00460	GEAR 1ST WHEEL (36T)	5637	34-01050	PIN	49226	34-01600	SCREW
77	34-02230	HEAD CYLINDER 1	4032	34-00470	GEAR 2ND WHEEL (33T)	5645	34-01060	NEUTRAL SWITCH ASSY	49227	34-01610	SCREW
82	31-03266	FLY-WHEEL ASSY	4033	34-00480	GEAR 3RD WHEEL (29T)	5650	34-01070	PIN	49228	34-01620	BOLT
99	34-00060	SHIFT CAM	4034	34-00490	GEAR 4TH WHEEL (27T)	5653	34-01080	AXLE DRIVE GEAR	49230	34-01630	SCREW WITH WASHER
111	34-02240	PLUG SPARK	4035	34-00500	GEAR 5TH WHEEL (25T)	5661	34-01090	PIN DOWEL	49236	34-01640	BOLT HEXAGON SOCKET
212	34-00081	COVER CLUTCH SIDE	4036	34-00510	GEAR 6TH WHEEL (24T)	5663	34-01100	PIN DOWEL	49238	34-01650	BOLT HEXAGON SOCKET
213	34-00091	COVER OIL PUMP	4040	34-00520	IDLE GEAR	5665	34-01110	ROD, PUSH	49244	34-02190	BOLT HEXAGON SOCKET
214	34-00101	COVER FLYWHEEL SIDE	4045	34-00530	STARTING GEAR	5670	34-01120	PIN PISTON	49245	34-01670	BOLT HEXAGON SOCKET
332	34-00110	FORK	4048	34-00540	GEAR IMPELLER SHAFT	6013	34-01130	COVER HOUSING	49246	34-01680	BOLT HEXAGON SOCKET
333	34-00120	FORK 1	4049	34-00550	PUMP DRIVEN GEAR	6015	34-02340	REED VALVE ASSY	49248	34-01690	BOLT HEXAGON SOCKET
334	34-00130	FORK 2	4060	34-00560	GEAR DRIVE	9323	34-01150	STOP RING	49251	34-01700	BOLT HEXAGON SOCKET
335	34-00140	FORK 3	4061	34-00570	GEAR BALANCE WEIGHT	9351	34-01160	CIRCLIP	49255	34-01710	BOLT HEXAGON SOCKET
381	34-02250	CRANKSHAFT ASSY	4066	34-00580	STARTING SLIDING	9352	34-01170	CIRCLIP	49281	34-01720	BOLT HEXAGON HEAD
382	34-02260	CONNECTING ROD COMPLETE	4610	34-00590	SPRING TENSION	9355	34-01180	CIRCLIP	49290	34-01730	BOLT HEXAGON
435	34-00170	PUSH LEVER ASSY	4620	34-00600	SPRING COMPRESSION	9356	34-01190	CIRCLIP	49292	34-02180	SCREW
471	34-00180	SPRING TORSION HUB	4625	34-00610	SPRING	9362	34-01200	SNAP RING	49294	34-01740	SCREW
582	34-02210	SPROCKET TH.11	4635	34-00620	SPRING	9363	34-01210	SNAP RING	34-02430	THERMOSTAT ASSY	
606	27-19791	MANIFOLD	4650	34-00630	SPRING	9365	34-01220	CIRCLIP	49405	34-02350	GASKET
641	34-02271	OIL PUMP -MIKUNI-	4655	34-00640	SPRING	15270	34-01230	OIL BREATHER PIPE	49840	34-01750	SCREW
657	34-00210	HOLDER	4660	34-00650	SPRING TORSION	15320	34-01241	KIT DEVIATING PIPE	53309	34-00821	GASKET H.COVER 2
658	34-00220	HOLDER	4665	34-00660	SPRING	24107	34-02140	PIPE 2	53310	34-01761	GASKET H.COVER 1
681	34-02280	PISTON RING SET (STD)	4680	34-00670	WASHER CONICAL SPRING	49004	34-01250	CLIP	53508	34-01770	OIL SEAL
701	34-02220	CRANKCASE ASSY	5101	34-00680	NEEDLE BEARING	49005	34-02160	CLAMP HOSE			
820	28-97810	BASE ASSY	5106	34-00690	BUSH SOLID	49007	34-01260	CLAMP			
826	27-00361	ROTOR ASSY	5113	34-00700	ROLLER BEARING	49009	34-01270	KEY			
828	25-60166	PLATE	5146	34-00710	BEARING	49010	34-01280	KEY			
911	34-00240	AXLE MAIN	5148	34-00720	BEARING	49015	34-01290	KEY			
912	34-00250	KICK STARTER SHAFT	5156	34-00730	BEARING	49022	34-02170	CLAMP HOSE			
914	34-00260	AXLE DRIVE	5172	34-00740	BEARING	49035	34-01300	NUT HEXAGON			
915	34-00270	SHIFT SHAFT	5178	34-00750	BEARING	49037	34-01310	NUT CAP	13-32366-3	FLYWELL COVER DECALCS	
917	34-00280	WEIGHT 1	5181	34-00760	BALL	49040	34-01320	NUT HEXAGON	13-32366-4	CLUTCH COVER DECALCS	
2430	34-00291	RUBBER	5182	34-00770	BALL	49041	34-01330	NUT HEXAGON			
2467	34-00300	JT.HOSE 2	5303	34-00790	O-RING	49042	34-01340	NUT HEXAGON	34-01780	AXLE MAIN ASSY	
2472	34-00310	SPACER REED VALVE	5308	34-00800	O-RING	49049	34-01350	NUT HEXAGON	34-01790	AXLE DRIVE ASSY	
2478	34-00321	RUBBER	5310	34-02200	O-RING	49056	34-01360	NUT	34-02121	COVER ASSY (GOLD STAMP)	
2492	34-00330	PLUG, OIL	5315	34-00831	O-RING	49068	34-01370	FORK SPACER	34-01810	GEAR BOX ASSY	
2495	34-02290	HOSE, OIL 2	5318	34-00840	O-RING	49070	34-01380	COLLAR	34-01820	CLUTCH GEARS	
2496	34-00350	HOSE, OIL 1	5320	34-00850	GASKET CYLINDER	49074	34-01390	PLATE THRUST	34-01831	GASKET SET	
2635	34-02150	CLAMP	5327	34-00860	GASKET CRANKCASE COVER 2	49084	34-01400	BOLT STUD	34-01840	OIL SEAL SET	
2657	34-00360	HOLDER	5341	34-00870	GASKET HOUSING COVER	49095	34-01410	WASHER PLAIN	34-02370	PISTON ASSY (STD)	
3511	34-00370	PLATE PRESSURE	5357	34-00880	GASKET	49101	34-01420	WASHER TOOTHED LOCK	34-02380	PISTON ASSY (OVERSIZE)	
			5358	34-00890	GASKET	49120	34-01430	WASHER PLAIN	34-02390	PISTON RING SET OVERSIZE	
			5359	34-00900	WASHER PLAIN	49122	34-01440	WASHER PLAIN	34-02400	CYLINDER-PISTON ASSY	
			5361	34-00910	GASKET	49124	34-01450	WASHER PLAIN			
			5362	34-00920	GASKET	49131	34-01460	WASHER			
			5371	34-02310	OIL SEAL	49132	34-01470	PLATE THRUST			
			5372	34-02320	OIL SEAL	49135	34-01480	WASHER PLAIN			
			5376	34-02330	OIL SEAL		34-01490	WASHER PLAIN			
			5395	34-00960	OIL SEAL	49139	34-01500	WASHER PLAIN			

S. CASINI 24-11-2004

SUPPLEMENTARY PARTS LIST